

#7000
SINGLE SWITCH



#7001
DUPLEX



#7002
SINGLE 1.25" HOLE



#7003
SINGLE 3/8" HOLE



#7004
SINGLE 5/8" HOLE




#7005
SINGLE BLANK



#7006
SINGLE DESPARD



#7007
SIX DUPLEX




#7009
SINGLE DECORA




#7010
DOUBLE DECORA



#7011
DOUBLE SWITCH



#7012
COMBINATION




#7013
DOUBLE DUPLEX




#7014
COMBO SWITCH/DECORA



#7015
DOUBLE BLANK




#7016
DOUBLE SWITCH/DUPLEX



#7017
DOUBLE DESPARD




#7018
TRIPLE DECORA




#7019
TRIPLE DESPARD




#7020
FOUR SWITCH




#7027
TRIPLE SWITCH




#7028
COMBO DECORA/DUPLEX




#7029
DIMMER 1/2" HOLE



#1005
SELF ADHESIVE PULL
(LOW PROFILE)
BLACK



#10168
SELF ADHESIVE KNOB



#7008
SELF ADHESIVE PULL

